

Floor to Ceiling Hoarding Systems

ENVIRO WALL

Page 1 of 2

1. Clear area for installation and remove all hazards
2. Mark out floor for bottom tracking with low tack tape or erasable marker.
3. Cut in bottom track (code: EB4-30, 20mm deep channel) and fix to floor. Make provision for door openings if required.
4. Fix wall starters as required (either bottom or top track – refer point 8)
5. Fix top track (code: ET4-30, 45mm deep channel) to ceiling, or structural overhead member as required.
6. Place in Enviro Wall panels and cut down to height if required using a scoring knife, fine-toothed handsaw, jigsaw or circular saw. If panels can be slipped into place from the open end of tracking, provide 5-15mm clearance. If panels are fitted from front on, cut panel to length 25mm shorter than the ceiling height to allow the panel to lift up into the top track and drop down into the bottom track.
7. Cut in and place joiner sections (code: EJ4-27 to EJ4-54) between each panel as they are fitted.
8. The last panel may need to be cut for width to allow clearance. If the last panel is to be fitted tight against an existing wall, you may require a top track section, or EC90-30 angle, to be fitted as the wall starter, to allow for the clearance that the panel needs to slip in to the joiner section.
9. If the ceiling height is greater than a full height panel, cut the joiner sections to the full floor-to-ceiling height. Place the full panel into the bottom track and wall starter/joiner section. Cut a joiner section (approx 1060mm long when using full width panels) as a horizontal joiner between the panels. Then cut a small panel from an Enviro Wall panel, 25mm shorted to allow the panel to lift up into the top track and drop down into the horizontal joiner.
10. Fit 90 degree or 45 degree external corners where required. Corners can be formed using the PVC corner (code: HPC-), or the aluminium corner (code: EC90-30). Where aluminium corners are used, one each side of the panels is recommended. To form a 135 degree corner, use 2 of the aluminium profile (code: EC45-30). Corners should be screwed together, through the panels.
11. Door + jamb installation- Assemble the precut aluminium jamb with the corner stakes supplied. We stock standard sizes of internal readycote doors. Openings for single doors can be cut out of a full panel if desired. Alternatively, they can be installed against a joiner, with and infill panel cut in over the door head. Double doors, generally, would start or finish against a joiner. Hang doors and fix jamb to surrounding panels. Doors should be orientated so that the swing path is into the construction side.
12. Doors can also be made using the Enviro Wall panels. Top tracks can be used as the top, bottom and stile members to frame the door. These members can be screwed to the face of the Enviro Wall. If additional strength for the stiles is required, a horizontal flat bar, or a piece of bottom track, can be used at mid-height.
13. If the hoarding requires greater stability, attach additional bracing to suitable adjacent walls, floors or ceilings as required.

Floor to Ceiling Hoarding Systems

ENVIRO WALL

Page 2 of 2

PLEASE NOTE:

- A. It is the responsibility of the purchaser and installer to ensure that the hoarding system is suitable and safe for the application and is installed in a secure manner. Consideration may need to be given to any potential wind load from external wall openings, doors and/or window openings, and any other loads that may be applied.
- B. The installation method and fixing requirements are to be assessed by a competent trades person, who is responsible to ensure that the install is carried out accordingly. The advice of a qualified engineer may be required to ascertain if an existing structure is capable of supporting the expected loads imposed on it by a temporary hoarding.
- C. Protecta Group can provide general advice, however final responsibility lies with the purchaser and installer.
- D. The use of Protecta Group hoardings for other applications, (eg:- edge protection, or where a wind load may apply, etc.) may require a qualified engineer to assess an appropriate support system.
- E. For hoardings exceeding a full panel in height (3.0m), consideration may need to be given to bracing or strengthening the EJ4 'H' joiners.
- F. The purchaser and/or the user must ensure that, if tapes are to be used, they are appropriate for the purpose, and that tapes are not used on finished surfaces where they could cause damage or leave residue.
- G. Appropriate warning signage, if required, is the responsibility of the purchaser and/or the installer.
- H. Exclusion zones may be required if machinery such as scissor lifts, forklifts etc, are to be used in proximity to the hoarding.
- I. Components to be reused on multiple installations should be inspected between installations to determine they are fit for reuse.
- J. Enviro Wall is not intended for use in areas where it is likely to come in contact with liquids